

Remote Controller User Guide

Remove the plastic tab beneath the battery first.

Press any button and check if the red light near ON/OFF flashes. If it does not, the battery connection might be loose. Adjust the battery and try again.

Entering Pairing Mode: The remote controller has a 7-second pairing window after power-on. After 7 seconds, it will no longer respond. If you need to pair again, disconnect power for 30 seconds and then power on again.

Pairing Method: In pairing mode, press the power button (up button) 4 times (or more) in quick succession. The light will start flashing. At this point, briefly press the remote control mode switch button (down button) once. The light will flash rapidly 10 times, indicating successful pairing.

Delete Pairing: Same method as pairing.

Brightness: 4 brightness levels available. Default brightness level 3 is the factory setting.

Mode: Switch mode controls the speed of the light movement completing one full cycle - either 24 hours or 1 minute. The default setting uses the 1-minute speed.

